

MOUVEMENTS A LA SURFACE A346 - B748 - A124 - A388 - B773 - C5M - A35K

BALE MULHOUSE

Ground movements A346 - B748 - A124 - A388 - B773 - C5M - A35K

AVERTISSEMENTS / WARNINGS

Voir restrictions complémentaires de roulage /
See additional taxiing restrictions :
AD 2 LFSB.20

Points situés sur des TWY.

Etre très attentif aux clairances de traversée, alignement piste et roulage sur TWY. La traversée ou l'alignement piste, ainsi que le roulage sur les TWY ne s'effectuent que sur **clairance explicite du contrôle**.
Le **collationnement** de toute instruction est **exigé**.

HS1 : l'exploitation de l'aire de maintenance Sud-Ouest fait l'objet d'un protocole définissant les conditions de gestion des entrées et sorties de cette aire de maintenance. (voir AD 2 LFSB.20.3.2.3).

Holding points located on TWY.

Particular attention shall be paid to the crossing, lining up and taxiing clearances. For crossing or lining up on RWY as well as taxiing on TWYs, an **explicit control clearance must be obtained**.

Readback is required for any instruction.

HS1 : The use of the South-West area is subject to a protocol that defines the conditions for managing the entries/exits in/from this maintenance area.
(See AD 2 LFSB.20.3.2.3).

 TWY interdits A 346 - B748 - A124 - A388 - B773 - C5M - A35K.
TWY prohibited A346 - B748 - A124 - A388 - B773 - C5M - A35K.

Postes de stationnement dédiés sur le parking principal : F8, F21-F22, 5 et 18.
Postes de stationnement aire de maintenance Sud-Ouest :
contacter les sociétés gestionnaires.

Dedicated parking stands on the main apron : F8, F21-F22, 5 and 18.
Available parking stands on the South-West Maintenance Area :
contact the managing companies.

LEGENDE / KEY

- ... Barre d'arrêt / Stop bar
- Point d'attente / Holding point
- Point d'attente intermédiaire
Intermediate holding point

 Aire de trafic / Apron

 Wig-Wag

 Point chaud / Hot spot
HS

0 500 m

Aire de maintenance
Sud-Ouest
South-West
maintenance area

