

CARTE D'AERODROME

Aerodrome chart

ATS : TWR HOR NOTAM ☎ (689) 40 60 50 70

BORA BORA MOTU MUTE

16 26 37 S - 151 45 09 W

ALT AD : 14 (1 hPa)

