

LOCATION INDICATORS

LOCATION INDICATORS / CODING

Indicateur souligné : aéroport non relié au RSFTA / Location indicator underlined : aerodrome not connected to the AFTN

LOCATION INDICATORS / DECODING

INDICATEUR INDICATOR	EMPLACEMENT LOCATION	INDICATEUR INDICATOR	EMPLACEMENT LOCATION	INDICATEUR INDICATOR	EMPLACEMENT LOCATION
FMCZ	DZAOUZDI Pamandzi				
FMEE	LA REUNION Roland Garros				
FMEH	SAINT PAUL L'ERMITAGE				
FMEL	SAINT PAUL L'EPERON				
FMEM	MAFATE - LA NOUVELLE - CIRQUE DE MAFATE				
FMEN	SAINT DENIS CHU				
FMEP	SAINT PIERRE Pierrefonds				
FMES	SAINT PIERRE CHU SUD				

Indicateur souligné : aéroport non relié au RSFTA / Location indicator underlined : aerodrome not connected to the AFTN