


# TMA TAHITI

## SID CONV RWY 04 TAHITI FAA'A

ATIS : TAHITI 128.800  
 TWR : TAHITI Tour / Tower 118.100  
 APP : TAHITI Approche / Approach 121.300

**Consignes générales**

Certains départs sont assortis de limitation de vitesse ou de pente minimale. En cas d'impossibilité, le pilote doit en aviser le contrôle lors du premier contact.

**Panne de radiocommunication**

En VMC : faire demi-tour et atterrir sur la piste en service au moment du départ.  
 En IMC : poursuivre son vol jusqu'aux limites de la CTR, au dernier niveau assigné et ensuite entreprendre la montée vers le niveau plan de vol.

**General instructions**

Some departures can be accompanied by speed limitations or minimum slope. In case of impossibility, the pilot must advise ATC at the first contact.

**Radiocommunication failure**

In VMC : reverse your course and land on the RWY in use at the moment of the departure.  
 In IMC : proceed to the limits of the CTR, at the last assigned FL, then, start climbing towards the FL as stipulated in the current flight plan.