

PARIS CHARLES DE GAULLE (LFPG)
STAR RNAV Réacteurs et Hélices / Turboprops
RWY 27R

STAR RNAV RWY 27R											
RMK							MAG VAR 2020 1,1°E			REF NAVAID : -	
Procedure Identification	Path Terminator	Waypoint Identification	Fly Over	Direction MAG (°)	Direction True (°)	Distance (NM)	Turn direction	MNM Altitude (FL or AMSL ft)	MAX Altitude (FL or AMSL ft)	MAX IAS (kt)	Navigation Accuracy (NM)
ROMGO 9W (UIR FIR)											
-	IF	ROMGO	-	-	-	-	-	-	-	300	-
-	TF	FF501	-	061	062.4	8.5	-	FL190	FL190	-	1.0
-	TF	NERKI	-	062	062.6	13.2	-	-	FL160	-	1.0
-	TF	BANOX	-	062	062.6	8.0	-	FL140	FL150	300	1.0
KEPER 9P (UIR)											
-	IF	KEPER	-	-	-	-	-	-	FL280	-	-
-	TF	LUMAN	-	034	035.1	9.8	-	-	-	300	1.0
-	TF	ROMGO	-	034	035.1	30.0	-	-	-	300	1.0
-	TF	FF501	-	061	062.4	8.5	-	FL190	FL190	-	1.0
-	TF	NERKI	-	062	062.6	13.2	-	FL140	FL140	-	1.0
-	TF	BANOX	-	062	062.6	8.0	-	FL140	FL140	300	1.0
KOVAK 9P (FIR)											
-	IF	KOVAK	-	-	-	-	-	-	-	300	-
-	TF	BENAR	-	344	345.3	16.1	-	-	-	-	1.0
-	TF	ROMGO	-	034	035.4	6.9	-	-	-	300	1.0
-	TF	FF501	-	061	062.4	8.5	-	-	-	-	1.0
-	TF	NERKI	-	062	062.6	13.2	-	FL140	FL140	-	1.0
-	TF	BANOX	-	062	062.6	8.0	-	FL140	FL140	300	1.0
SABLE 9P (FIR)											
-	IF	SABLE	-	-	-	-	-	-	-	-	-
-	TF	LUMAN	-	078	078.8	27.3	-	-	-	300	1.0
-	TF	ROMGO	-	034	035.1	30.0	-	-	-	300	1.0
-	TF	FF501	-	061	062.4	8.5	-	-	-	-	1.0
-	TF	NERKI	-	062	062.6	13.2	-	FL140	FL140	-	1.0
-	TF	BANOX	-	062	062.6	8.0	-	FL140	FL140	300	1.0
ROMGO 9P (UIR FIR)											
-	IF	ROMGO	-	-	-	-	-	-	-	300	-
-	TF	FF501	-	061	062.4	8.5	-	FL190	FL190	-	1.0
-	TF	NERKI	-	062	062.6	13.2	-	FL140	FL140	-	1.0
-	TF	BANOX	-	062	062.6	8.0	-	FL140	FL140	300	1.0
KEPER 9X (UIR, Réacteurs uniquement / Jets only, Sur instruction / On instruction)											
-	IF	KEPER	-	-	-	-	-	-	-	-	-
-	TF	LUMAN	-	034	035.1	9.8	-	-	-	-	1.0
-	TF	BENAR	-	034	035.1	23.1	-	-	-	-	1.0
-	TF	ROMGO	-	034	035.4	6.9	-	-	FL240	300	1.0
-	TF	NERKI	-	061	062.4	21.7	-	-	FL190	-	1.0
-	TF	BANOX	-	062	062.6	8.0	-	FL170	FL180	300	1.0
→	KOVAK 9X (FIR, Réacteurs uniquement / Jets only, Sur instruction / On instruction)										
→	-	IF	KOVAK	-	-	-	-	-	FL190	-	-
→	-	TF	BENAR	-	344	345.3	16.1	-	-	-	1.0
→	-	TF	ROMGO	-	034	035.4	6.9	-	-	300	1.0
→	-	TF	NERKI	-	061	062.4	21.7	-	-	-	1.0
→	-	TF	BANOX	-	062	062.6	8.0	-	FL180	300	1.0