

MARSEILLE PROVENCE
Départs RNAV initiaux RWY 31
Initial RNAV departures RWY 31

FREQ : voir/see AD 2 LFML COM 01



RNAV 1
GNSS ou/ou DME/DME*
*(IRU requis/required)

