

APPROCHE AUX INSTRUMENTS

TOUSSUS LE NOBLE

Instrument approach



CAT A B C

ALT AD : 538 (20 hPa), THR : 538

FNA VOR Z RWY 07L

FREQ : Voir/see AD 2 LFPN COM 01
Absence ATS : **A/A** FR uniquement. Obtenir le QNH auprès de ATIS ORLY
A/A FR only. Obtain QNH on ATIS ORLY

VAR
1°E
(20)



→ THR (NM) 10.1 7.6 1.6
→ DME TNO (NM) 10.5 8 2

MNM AD : distances verticales en pieds, RVR et VIS en mètres. / Vertical distances in feet, RVR and VIS in metres. REF HGT : ALT AD

CAT	VOR Z			MVL/Circling (1)		MVL/Circling Absence ATS		DME TNO						
	MDA (H)	RVR	OCH	MDA (H)	VIS	MDA (H)	VIS	NM	7	6	5	4	3	2
A	920 (380)	1500	373	1040 (500)	1500	1070 (530)	1500	ALT	2670	2350	2030	1710	1400	1080
B	920 (380)	1500	380	1150 (610)	1600	1180 (640)	1600	(HGT)	(2132)	(1812)	(1492)	(1172)	(862)	(542)
C	950 (410)	1900	410	1240 (710)	2400	1270 (740)	2400							

Observations : (1) Circuit AD RWY 07L : Droite. Circuit AD RWY 07/25 : 1200 ft AMSL.
Remarks : (1) AD Circuit RWY 07L : Right hand. AD Circuit RWY 07/25 : 1200 ft AMSL.

	7.6 NM	70 kt	85 kt	100 kt	115 kt	130 kt	145 kt	160 kt
FAF - THR		6 min 30	5 min 21	4 min 33	3 min 57	3 min 30	3 min 08	2 min 50
VSP (ft/min)		370	450	530	610	685	765	845