

**APPROCHE AUX INSTRUMENTS**

**RENNES SAINT JACQUES**


Instrument approach

CAT A B C D


ALT AD : 124, DTHR : 81 (3 hPa)

FNA VOR RWY 10

FREQ : voir / see AD 2 LFRN COM 01	VAR 0° (20)
------------------------------------	-------------------



TA : 5000



→ DTHR (NM)	8.8	5.9	0.6
→ DME REN (NM)	9.0	6.1	0.8

MNM AD : distances verticales en pieds, RVR et VIS en mètres / vertical distances in feet, RVR and VIS in metres. REF HGT : ALT DTHR

CAT	VOR			MVL/Circling		DME REN					
	MDA (H)	RVR	OCH	MDA (H)	VIS	NM	6	5	4	3	2
A				720 (640)	2200	ALT	1970	1650	1330	1020	700
B	560 (480)	2200	472	780 (700)	2200	(HGT)	(1889)	(1569)	(1249)	(939)	(619)
C				870 (790)	2400						
D				1040 (960)	3600						

FAF - DTHR	5.9 NM	70 kt	90 kt	100 kt	120 kt	140 kt	160 kt	190 kt
FAF - MAPT	5.3 NM	5 min 03	3 min 56	3 min 32	2 min 57	2 min 32	2 min 13	1 min 52
VSP (ft/min)		4 min 33	3 min 32	3 min 11	2 min 39	2 min 16	1 min 59	1 min 40
		370	480	530	640	740	850	1010